

# User Guide

Kyocera  
SE47



## User Guide for the Slider V5 / \*MTV Edition phone

This manual is based on the production version of the Kyocera SE47 phone. Software changes may have occurred after this printing. Kyocera reserves the right to make changes in technical and product specifications without prior notice. The products and equipment described in this documentation are manufactured under license from QUALCOMM Incorporated under one or more of the following U.S. patents:

4,901,307	5,056,109	5,099,204	5,101,501	5,103,459
5,107,225	5,109,390	5,193,094	5,228,054	5,257,283
5,265,119	5,267,261	5,267,262	5,280,472	5,283,536
5,289,527	5,307,405	5,309,474	5,337,338	5,339,046
5,341,456	5,383,219	5,392,287	5,396,516	D356,560
5,408,697	5,414,728	5,414,796	5,416,797	5,426,392
5,437,055	D361,065	5,442,322	5,442,627	5,452,473
5,461,639	5,469,115	5,469,471	5,471,497	5,475,870
5,479,475	5,483,696	5,485,486	5,487,175	5,490,165
5,497,395	5,499,280	5,504,773	5,506,865	5,509,015
5,509,035	5,511,067	5,511,073	5,513,176	5,515,177
5,517,323	5,519,761	5,528,593	5,530,928	5,533,011
5,535,239	5,539,531	5,544,196	5,544,223	5,546,459
5,548,812	5,559,881	5,559,865	5,561,618	5,564,083
5,566,000	5,566,206	5,566,357	5,568,483	5,574,773
5,574,987	D375,740	5,576,662	5,577,022	5,577,265
D375,937	5,588,043	D376,804	5,589,756	5,590,069
5,590,406	5,590,408	5,592,548	5,594,718	5,596,570
5,600,754	5,602,834	5,602,833	5,603,096	5,604,459
5,604,730	5,608,722	5,614,806	5,617,060	5,621,752
5,621,784	5,621,853	5,625,876	5,627,857	5,629,955
5,629,975	5,638,412	5,640,414	5,642,398	5,644,591
5,644,596	5,646,991	5,652,814	5,654,979	5,655,220
5,657,420	5,659,569	5,663,807	5,666,122	5,673,259
5,675,581	5,675,644	5,680,395	5,687,229	D386,186
5,689,557	5,691,974	5,692,006	5,696,468	5,697,055
5,703,902	5,704,001	5,708,448	5,710,521	5,710,758
5,710,768	5,710,784	5,715,236	5,715,526	5,722,044
5,722,053	5,722,061	5,722,063	5,724,385	5,727,123
5,729,540	5,732,134	5,732,341	5,734,716	5,737,687
5,737,708	5,742,734	D393,856	5,748,104	5,751,725

5,751,761	5,751,901	5,754,533	5,754,542	5,754,733
5,757,767	5,757,858	5,758,266	5,761,204	5,764,687
5,774,496	5,777,990	5,778,024	5,778,338	5,781,543
5,781,856	5,781,867	5,784,406	5,784,532	5,790,589
5,790,632	5,793,338	D397,110	5,799,005	5,799,254
5,802,105	5,805,648	5,805,843	5,812,036	5,812,094
5,812,097	5,812,538	5,812,607	5,812,651	5,812,938
5,818,871	5,822,318	5,825,253	5,828,348	5,828,661
5,835,065	5,835,847	5,839,052	5,841,806	5,842,124
5,844,784	5,844,885	5,844,899	5,844,985	5,848,063
5,848,099	5,850,612	5,852,421	5,854,565	5,854,786
5,857,147	5,859,612	5,859,838	5,859,840	5,861,844
5,862,471	5,862,474	5,864,760	5,864,763	5,867,527
5,867,763	5,870,427	5,870,431	5,870,674	5,872,481
5,872,774	5,872,775	5,872,823	5,877,942	5,878,036
5,870,631	5,881,053	5,881,368	5,884,157	5,884,193
5,884,196	5,892,178	5,892,758	5,892,774	5,892,816
5,892,916	5,893,035	D407,701	5,898,920	5,903,554
5,903,862	D409,561	5,907,167	5,909,434	5,910,752
5,911,128	5,912,882	D410,893	5,914,950	5,915,235
5,917,708	5,917,811	5,917,812	5,917,837	5,920,284
D411,823	5,923,650	5,923,705	5,926,143	5,926,470
5,926,500	5,926,786	5,930,230	5,930,692	

Other patents pending.

Kyocera is a registered trademark of Kyocera Corporation. Brick Attack, Doodler, and Race 21 are trademarks of Kyocera Wireless Corp. Tetris is a registered trademark of Elorg Company LLC. eZiText is a registered trademark of Zi Corporation. Virgin, the Virgin signature, and the Virgin Mobile trademark and logo are registered trademarks of Virgin Enterprises Ltd. MTV: Music Television, \*MTV and all related titles and logos are trademarks of MTV Networks, a division of Viacom International Inc. All other trademarks are the property of their respective owners.

Ringtones Copyright © 2003 Virgin Enterprises Ltd.  
Copyright © 2003 Kyocera Wireless Corp.  
Copyright © 2003 MTV Networks. All rights reserved.  
82-K5484-1EN, Rev 001

## **FCC/IC Notice**

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

To maintain compliance with FCC RF exposure guidelines, if you wear a handset on your body, use the Kyocera Wireless Corp. (KWC) supplied and approved holster (TXLCC10049). Use of other accessories may not ensure compliance with FCC RF exposure guidelines.

### **THIS MODEL PHONE MEETS THE GOVERNMENT'S REQUIREMENTS FOR EXPOSURE TO RADIO WAVES.**

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg.\* Tests for SAR are

conducted using standard operating positions specified by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands.

Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government-adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR values for this model phone are:

CDMA mode (Part 22)–head: 1.22 W/kg, Body-worn: 0.56 W/kg with KWC holster TXLCC10049;  
PCS/CDMA mode (Part 24)–head: 0.71 W/kg, Body-worn: 0.57 W/kg with KWC holster TXLCC10049.

(Body-worn measurements differ among phone models, depending upon available accessories and FCC requirements). The body-worn SAR values provided above were obtained by using KWC supplied and approved holster TXLCC10049).

While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF emission guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section <http://www.fcc.gov/oet/fccid> after searching on FCC ID **OVFKWC-SE47**. Additional information on SAR can be found on the Cellular Telecommunications and Internet Association (CTIA) web-site at <http://www.wow-com.com>.

\* In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

### **Caution**

The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the warranty and user's authority to operate the equipment.

### **Warning**

Use only Kyocera approved accessories with Kyocera phones. Use of any unauthorized accessories (includes faceplates/front housings) may be dangerous and will invalidate the phone warranty if said accessories cause damage or a defect to the phone.

### **Optimize your phone's performance**

Use the guidelines on page 2 to learn how to optimize the performance and life of your phone and battery.

### **Air bags**

If your vehicle has an air bag, DO NOT place installed or portable phone equipment or other objects over the air bag or in the air bag deployment area. If equipment is not properly installed, you and your passengers risk serious injury.

### **Medical devices**

Pacemakers—Warning to pacemaker wearers: wireless phones, when in the 'on' position, have been shown to interfere with pacemakers. The phone should be kept at least six (6) inches away from the pacemaker to reduce risk. The Health Industry Manufacturers Association and the wireless technology research community recommend that you follow these guidelines to minimize the potential for interference.

- Always keep the phone at least six inches (15 centimeters) away from your pacemaker when the phone is turned on.
- Do not carry your phone near your heart.
- Use the ear opposite the pacemaker.
- If you have any reason to suspect that interference is taking place, turn off your phone immediately.

Hearing aids—Some digital wireless phones may interfere with hearing aids. In the event of such interference, you may want to consult your service provider or call the customer service line to discuss alternatives.

Other medical devices—If you use any other personal medical device, consult the manufacturer of the device to determine if it is adequately shielded from external RF energy. Your physician may be able to help you obtain this information.

In health care facilities—Turn your phone off in health care facilities when instructed. Hospitals and health care facilities may be using equipment that is sensitive to external RF energy.

### **Potentially unsafe areas**

**Posted facilities**—Turn your phone off in any facility when posted notices require you to do so.

**Aircraft**—FCC regulations prohibit using your phone on a plane that is in the air. Turn your phone off or switch it to Airplane Mode (page 12) before boarding aircraft.

**Vehicles**—RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer of the device to determine if it is adequately shielded from external RF energy.

**Blasting areas**—Turn off your phone where blasting is in progress. Observe restrictions, and follow any regulations or rules.

**Potentially explosive atmospheres**—Turn off your phone when you are in any area with a potentially explosive atmosphere. Obey all signs and instructions. Sparks in such areas could cause an explosion or fire, resulting in bodily injury or death. Areas with a potentially explosive atmosphere are often, but not always, clearly marked. They include:

- fueling areas such as gas stations
- below deck on boats
- transfer or storage facilities for fuel or chemicals
- vehicles using liquefied petroleum gas, such as propane or butane

- areas where the air contains chemicals or particles such as grain, dust, or metal powders
- any other area where you would normally be advised to turn off your vehicle engine

### **Use with care**

Use only in normal position (to ear). Avoid dropping, hitting, bending, or sitting on the phone.

### **Keep phone dry**

If the phone gets wet, turn the power off immediately and return it to the dealer for service.

### **Resetting the phone**

If the screen seems frozen and the keypad does not respond to keypresses, reset the phone by removing and replacing the battery (see page 1).

If the problem persists, return the phone to the dealer for service.

### **Qualified service**

If the problem with your phone persists, return the phone with all accessories and packaging to the dealer for qualified service.

### **Accessories**

Use only Kyocera-approved accessories with Kyocera phones. Use of any unauthorized accessories may be dangerous and will invalidate the phone warranty if said accessories cause damage or a defect to the phone.

To shop online for a Hands-free Car Kit and other phone accessories, visit [www.kyocera-wireless.com/store](http://www.kyocera-wireless.com/store).

To order by phone, call (800) 349-4188 (U.S.A. only) or (858) 882-1410.

## Radio frequency (RF) energy

Your telephone is a radio transmitter and receiver. When it is on, it receives and sends out RF energy. Your service provider's network controls the power of the RF signal. This power level can range from -50 to +28 dBm.

In August 1996, the U.S. Federal Communications Commission (FCC) adopted RF exposure guidelines with safety levels for hand-held wireless phones. These guidelines are consistent with the safety standards previously set by both U.S. and international standards bodies in the following reports:

- ANSI C95.1 (American National Standards Institute, 1992)
- NCRP Report 86 (National Council on Radiation Protection and Measurements, 1986)
- ICNIRP (International Commission on Non-Ionizing Radiation Protection, 1996)

Your phone complies with the standards set by these reports and the FCC guidelines.

## E911 Mandates

Where service is available, this handset complies with the Phase I and Phase II E911 Mandates issued by the FCC.

## Battery and charger specifications

Charger	Input	Output
TXTVL10034	100-240VAC/50/60Hz	4.5V 1.5A
TXACA10002	120VAC / 60Hz	5.2V 400mA
Standard Battery: 3.7V /1100mAh		

## Customer support

To contact Virgin Mobile's customer support department, dial \*VM from your Virgin Mobile phone or 888-322-1122 from any phone. They can answer questions about your phone, phone bill, call coverage area, and specific features available to you, such as call forwarding or voicemail.

For questions about the phone features, refer to the materials provided with your phone, or visit [www.virginmobileusa.com](http://www.virginmobileusa.com).

For additional questions, you may contact the Kyocera Wireless Corp. Customer Care Center in either of the following ways:

- Web site: [www.kyocera-wireless.com](http://www.kyocera-wireless.com)
- Email: [phone-help@kyocera-wireless.com](mailto:phone-help@kyocera-wireless.com)

Before requesting support, please try to reproduce and isolate the problem. When you contact the Customer Care Center, be ready to provide the following information:

- The name of your service provider.
- The actual error message or problem you are experiencing.
- The steps you took to reproduce the problem.
- The phone's electronic serial number (ESN).

To find the ESN:

- a. Remove the battery.
- b. Locate the white label on the back of the phone. Your phone's 11-digit ESN begins with "D" and is located on the label.

**Qualified service**

If the problem with your phone persists, return the phone with all accessories and packaging to the dealer for qualified service.

**Become a product evaluator**

To participate in the testing and evaluation of Kyocera Wireless Corp. products, including cellular or PCS phones, visit [beta.kyocera-wireless.com](http://beta.kyocera-wireless.com).



093 453 037

**Kyocera Wireless Corp.**

10300 Campus Point Drive, San Diego, CA 92121  
U.S.A.

Visit us at [www.kyocera-wireless.com](http://www.kyocera-wireless.com)

To purchase accessories, visit  
[www.kyocera-wireless.com/store](http://www.kyocera-wireless.com/store)



# CONTENTS

---

<b>1</b>	<b>Getting Started</b> . . . . .	<b>1</b>	<b>5</b>	<b>Sending and Receiving Text Messages</b> . . . . .	<b>20</b>
	Installing the battery . . . . .	1		Sending text messages . . . . .	20
	Charging the battery . . . . .	1		Retrieving text messages . . . . .	23
	Removing the battery . . . . .	2		Erasing messages . . . . .	24
	Caring for the battery . . . . .	2		Customizing message settings . . . . .	25
	Performing basic functions . . . . .	3	<b>6</b>	<b>VirginXtras</b> . . . . .	<b>27</b>
	Getting to know your phone . . . . .	4		Accessing VirginXtras . . . . .	27
	Using menus . . . . .	6		Navigating VirginXtras . . . . .	27
	Understanding screen icons . . . . .	7	<b>7</b>	<b>*MTV</b> . . . . .	<b>28</b>
<b>2</b>	<b>Your Account</b> . . . . .	<b>9</b>		Accessing *MTV . . . . .	28
	Checking your account balance . . . . .	9	<b>8</b>	<b>Games</b> . . . . .	<b>29</b>
	Top-Up your account . . . . .	9		Tetris . . . . .	29
<b>3</b>	<b>Making and Answering Calls</b> . . . . .	<b>10</b>		Brick Attack . . . . .	30
	Making a call . . . . .	10		Race 21 . . . . .	30
	Answering a call . . . . .	10		Doodler . . . . .	31
	Setting the phone to hold calls . . . . .	11		*MTV Games . . . . .	33
	Calling Emergency services . . . . .	12	<b>9</b>	<b>Storing Contacts</b> . . . . .	<b>34</b>
	Using your phone in an airplane . . . . .	12		Saving a contact entry . . . . .	34
	Dealing with missed calls . . . . .	13		Saving an email address, street address, URL, or note . . . . .	35
	Viewing recent call details . . . . .	13		Editing or erasing a contact . . . . .	36
	Speed dialing . . . . .	14		Editing a phone number . . . . .	36
	Setting up voicemail . . . . .	15		Finding contact information . . . . .	37
	Silencing an incoming call . . . . .	15	<b>10</b>	<b>Customizing Your Phone</b> . . . . .	<b>39</b>
	Using the speakerphone . . . . .	16		Silencing all sounds . . . . .	40
	Making calls using a headset . . . . .	16		Choosing a different Ringtone . . . . .	40
<b>4</b>	<b>Entering Letters, Numbers, and Symbols</b> . . . . .	<b>17</b>		Adjusting volume . . . . .	41
	Understanding text entry screens . . . . .	17			
	Text entry modes . . . . .	17			

Using shortcuts	.42
Personalizing the screen	.42
Creating a secure environment	.44
Setting message alerts	.46
Setting position location	.46
<b>11 Using Voice Recognition</b>	<b>.48</b>
Setting up voice dialing	.48
Calling using voice tags	.48
Using voice features with accessories	.50
Training voice recognition	.51
<b>12 Using Tools</b>	<b>.52</b>
Voice Memo	.52
Scheduler	.53
Alarm Clock	.53
Tip Calculator	.54
Calculator	.54
Timer	.54
Stopwatch	.55


# 1 GETTING STARTED

---

Your Slider V5 phone comes with an internal/removable lithium ion (LiIon) battery. **Fully charge the battery before using the phone.**

## Installing the battery


1. Hold the phone face down.
2. Place the battery on the bottom lip of the phone casing, aligning the metal contacts with those inside the phone.
3. Push down on the battery until it clicks into place.





## Charging the battery

The battery is partially charged when you receive your phone. You must have at least a partial charge in the battery to make or receive calls, regardless of whether the AC adapter is connected to the phone.

To charge the battery, connect the AC adapter to the jack at the bottom of the phone (as shown), then connect the adapter's plug to a wall outlet.



The battery icon in the upper-right corner of the screen tells you whether the phone is:

- Charging (the icon is scrolling)
- Partially charged 
- Fully charged 



**Note:** If you use the phone while the AC adapter is connected, the battery is not being charged.

## Recharging the battery

You can safely recharge the battery at any time, even if it has a partial charge.

## Removing the battery

1. Turn off the phone.
2. Hold the phone face down. Slide up the latch on the back of the phone.
3. Lift the battery away from the phone.



- Avoid exposing the battery to extreme temperatures, direct sunlight, or high humidity.
- Never dispose of any battery in or near a fire. It could explode.

## Common causes of battery drain

The following functions drain the battery more quickly and adversely affect talk and standby times:














- Playing games
- Using VirginXtras
- Keeping backlighting on
- Operating when far away from a base station or cell site
- Operating when no service is available, or service is available intermittently
- Using speakerphone mode
- Using high earpiece and ringer volume settings
- Repeating sound, vibration, or lighted alerts


## Caring for the battery

### General safety guidelines

- Do not take apart, puncture, or short-circuit the battery.
- If you have not used the battery for more than a month, recharge it before using your phone.

## Performing basic functions

To...	From the main screen...
Turn the phone on	Press and hold  until the startup animation appears.
Turn the phone off	Slide the phone up to open. Press and hold  until the shutdown animation appears.
Make a call	Slide the phone up to open. Extend the antenna. Enter the number and press  .
End a call	Slide the phone closed, or press  .
Answer a call	Slide the phone open. Extend the antenna. Press  .
Access voicemail	Select <b>Menu</b> → <b>Messages</b> → <b>Voicemail</b> . See <a href="#">page 15</a> for details.
Verify your phone number	Select <b>Menu</b> → <b>Phone Info</b> .
Silence the ringer	Press  or  ; then  to answer.
Access *MTV	Press and hold  .
Access VirginXtras	Press and hold  left.
View a list of recent calls	Press  down.
Silence all sounds	Press and hold  right.
Check your balance	Press and hold  up.



Check balance

Access VirginXtras


Silence all sounds

View recent calls


## Getting to know your phone

- 1 **Main screen.** Briefly press the End/Power key (item 5, below), to return from any other display to the phone's main screen.
- 2 **Menu key** provides access from the main screen to the menu when phone is open.
- 3 **Contacts key** provides shortcut from the main screen to your Contacts when phone is open (see [page 34](#)).
- 4 **Send/Talk key** answers a call or starts a call to a dialed number when phone is open. Also, one press activates voice dialing (see [page 48](#)), two presses displays a list of recent calls, and three presses redials the last number called.
- 5 **End/Power key** turns the phone on. Also turns phone off, ends a call, or returns you to the main screen when phone is open.
- 6 **Back key** erases the last character in text entry, or returns to the previous menu.
- 7 **Speakerphone key** answers calls and turns the speakerphone on and off.

**Important:** You must slide your phone open to use the keys.



- ⑧ **Navigation key** scrolls through lists and positions cursor. Also accesses shortcuts from the main screen:  
(left) accesses VirginXtras; (right) sets phone to vibrate only; (up) initiates a balance query;  
(down) lists recent calls.
- ⑨ **OK key** selects a menu item or option.
- ⑩ **Jack for Hands-free Headset** (sold separately) ⚠
- ⑪ **1 key** accesses voicemail and enters punctuation during text entry.
- ⑫ **Keypad** for entering numbers, letters, or symbols.
- ⑬ \* **Shift key**. Press and hold this key to access \*MTV. Also changes capitalization and text entry modes (see [page 17](#)).
- ⑭ **0 Next key** cycles through word choices during eZiText<sup>®</sup> text entry (see “[Entering words quickly](#)” on [page 18](#)).
- ⑮ **Space # key** enters a space during text entry. Also switches Silent Mode (vibrate only) on or off.
- ⑯ **Jack for AC Adapter** (included) ⚠



⚠ **Warning:** Inserting an accessory into the incorrect jack will damage the phone.

## Using menus

The contents of the main menu are as follows:



**Balance**  
Check Balance  
Top-Up



**Top-Up**



**Messaging**  
Send Text  
InBox  
Virgin Alerts  
Voicemail  
Net Alerts  
OutBox  
Saved  
Erase Msgs  
Group Lists  
Msg Settings



**VirginXtras**  
See the VirginXtras  
section on [page 27](#).



**\*MTV**  
Ringtones  
News  
Voting  
Txt2MTV  
Games  
Shows  
Audio Clips  
More



**Games**  
Tetris®  
Brick Attack™  
Race 21™  
Doodler™  
\*MTV Games



**Contacts**  
View All  
Add New  
Find Name  
Add Voice Dial  
Speed Dial List  
Voice Dial List  
Business List  
Personal List  
Information



**Recent Calls**  
All Calls  
Incoming Calls  
Outgoing Calls  
Missed Calls  
Erase Lists



**Settings**  
Silent Mode  
Sounds  
Display  
Voice Services  
Security  
Call Information  
Network  
Convenience  
Msg Settings  
Accessories










**Tools**  
Voice Memo  
Scheduler  
Alarm Clock  
Tip Calculator  
Calculator  
Timer  
Stopwatch



**Phone Info**  
Displays the model  
number, phone  
number, ESN, and  
software version  
your phone is  
using.

## To use menus



- From the main screen, press  to select **Menu**.
- Press  left, right, up, or down to move through the menus.\*\*
- Press  to select a menu or menu item.
- Press  up or down to view menu items.
- Press  to back up a menu level.
- Press  to return to the main screen.











\*\* To change the way the menus appear, select **Menu** → **Settings** → **Display** → **Main Menu View**, then select either **Graphic** or **List** and press .

**Note:** In this guide, the use of an arrow → tells you to select an option from a menu. For example, **Menu** → **Settings** means select **Menu**, then select the **Settings** option.

## Understanding screen icons

These icons may appear on your phone's screen.

-  The phone is operating in IS95 digital mode.
-  The phone is receiving a signal. You can make and receive calls. Fewer bars indicate a weaker signal.

-  The phone is set to show its position location to emergency services only.
-  The phone is set to show its position location to your service provider as well as to emergency services.
-  Service is available. You can make and receive calls.
-  Service is not available. You cannot make or receive calls.
-  Data is being transmitted.
-  The alarm clock is set.
-  The phone is in privacy mode or is accessing a secure Web site.
-  A Hands-Free kit is in use and Auto Answer is set to “After 5 Seconds.”
-  You have a text message, voicemail, or page. (If this icon is flashing, the message is urgent.)
-  The battery is fully charged. The more black bars, the greater the charge.

## Other icons



The item was erased.



A confirmation that the item was saved.



Information



Question



Attention, warning



Incoming voice call (unidentified).

Other images may be assigned to specific callers (see [page 34](#)).


## 2 YOUR ACCOUNT

---


You can manage your Virgin Mobile account from your phone. The basic tasks are summarized in this chapter. For more information about your account, contact Virgin Mobile.

### Checking your account balance


You can check your Virgin Mobile account balance in either of two ways:

1. At the main screen, press and hold  up.  
-or-
2. Select **Menu** → **Balance** → **Check Balance**.

- Your balance appears along with the number of minutes you've used that day.



- When your account is low or empty, you will receive a notification to Top-Up.



### Top-Up your account

Top-Up is how you increase your Virgin Mobile account balance. It's like putting gas in

your tank before you hit the road. You can Top-Up your Virgin Mobile account right from your phone. First you need to register your credit card at [www.virginmobileusa.com](http://www.virginmobileusa.com) or buy a Top-Up card from one of the thousands of stores that carry them.

When your balance is low, Top-Up your account from your phone as follows.

1. Select **Menu** → **Balance** → **Top-Up**.
2. Choose either credit card or Top-Up Card.
3. Follow the simple instructions to Top-Up your account.
4. To find a Top-Up store near you, select Find a Store from the Top-Up menu.



**Note:** You can also Top-Up over the Web at [www.virginmobileusa.com](http://www.virginmobileusa.com).


### For more information

For more information about your account balance and Virgin Mobile service, visit [www.virginmobileusa.com](http://www.virginmobileusa.com) or contact Virgin Mobile at (888) 322-1122.



## 3 MAKING AND ANSWERING CALLS

---

### Making a call



1. Make sure you are in an area where the signal can be received. Look for the  symbol on the main screen.

**Note:** The more bars you see in this symbol, the clearer the reception will be. If there are no bars, try moving to a location where the reception is better.

2. Slide the phone open and enter the phone number.
3. Press .
4. Press  to end the call.



**Tip:** To make calls using your phone's voice recognition feature, see “[Calling using voice tags](#)” on page 48.

### Redialing a number

To redial the last number called, press  twice. If you see a message prompting you to speak a name, press  again.




### Calling a saved number

If you have already saved a phone number, you can use the Contacts list to find it quickly.



1. From the main screen, press .  
This brings up a list of all saved contacts.
2. Scroll down the list, find the contact you want, and press  to dial the number.  
For more about contacts, see [page 37](#).

### Answering a call

When a call comes in, the phone rings, vibrates, and/or lights up (depending on your settings), and an animated graphic appears. The phone number of the caller also appears if it is not restricted. If the number is stored in your Contacts directory, the contact name appears.

- To answer the call, press .
- If you do not wish to answer the call, press  with or without sliding the phone open. This silences the ringer or ceases the vibration. You can also press  up or down. Either action

sends the caller to voicemail if you do not pick up the call.

- To place an incoming call momentarily on hold, slide open, press , and press  to select **Hold Call**.

**Note:** Before you can place calls on hold, you must first record a message and enable the Hold Call feature. See “[Setting the phone to hold calls](#)” and “[Placing an incoming call on hold](#)” below.

**Tip:** To answer calls using your phone's voice recognition feature, see “[Answering the phone](#)” on [page 50](#).

## Setting the phone to hold calls

The Hold Call setting allows you to place incoming calls on hold until you are ready to answer them.

To enable your phone to place calls on hold:

1. Select **Menu** → **Settings** → **Convenience** → **Hold Call**.
2. Select **Enabled**.
3. If you have not recorded a hold message, you will be prompted to record one.  
Example: “Please hold. I’ll answer in a minute.”
4. Record the message twice, as prompted.

## 5. Select **Save**, **Play**, or **Exit**.



The next time a call comes in, you will have the option of placing it on hold.

## Placing an incoming call on hold

You can place a call on hold once you have enabled the feature.

**Note:** If you are already on a call and you receive another call, you cannot place the incoming call on hold. It will go to voicemail.

To place a call on hold:

1. When a call comes in, press  right and press  to select **Hold Call**. The caller will hear your recorded hold message.
2. To speak to the caller, select **Answer**.  
-or-  
To hang up without speaking to the caller, select **End Call**.


## Changing the hold message

To change your hold message:

1. Select **Menu** → **Settings** → **Convenience** → **Hold Call** → **Re-record Msg.** and follow the prompts.


2. Record the message twice.
3. Select **Save, Play, or Exit**.

## Setting Open to Answer

The default setting on your phone requires you to slide it open and press  to answer an incoming call. You can set the phone to answer as soon as you open it.

1. Select **Menu** → **Settings** → **Convenience** → **Open to Answer**.
2. Select **Enabled**.



## Calling Emergency services

- Dial 911 and press .

You can call emergency services even if your phone is locked or your account is restricted. When you call, your phone enters **Emergency mode**. This enables the emergency service exclusive access to your phone to call you back, if necessary. To make or receive regular calls after dialing the code, you must exit this mode.

### To exit Emergency mode

When you have completed the emergency call:

1. Press  to select Exit.
2. Press  again to confirm your choice.

The phone returns to the main screen and you are ready to make and receive regular calls.

**Note:** To determine who has access to your location, see [“Setting position location” on page 46](#).



## Using your phone in an airplane


**Note:** Please check with uniformed crew personnel before operating your phone in Airplane mode.

While in an airplane, it is normally required that you turn off your mobile phone, because it emits RF signals that interfere with air traffic control. However, with permission of a crew member, you can keep your Slider v5 powered on if you set it to Airplane mode.


In Airplane mode, your phone will not emit RF signals. You cannot make or receive regular phone calls, send text messages, or use VirginXtras, but you can play games, use the Scheduler, set the clock, and make emergency calls to designated emergency services.



### To set Airplane mode:

1. Select **Menu** → **Settings** → **Convenience** → **Airplane Mode**.
2. At the message, press .
3. Press  to select an option:

- **Disabled**—Airplane mode is disabled. If necessary, press  to return to the home screen.
- **Enabled**—Turns off RF signals. The text “Phone Off” appears at the top of the main screen.

## Dealing with missed calls



When you have missed a call, “ **Missed**” appears on your screen.

- To view the caller’s number or name, select **Missed Calls**. In the Recent Calls list, the missed call is indicated with a flashing .
- Press  to clear the screen.
- If the caller left a voicemail message, select **Call**. If you have not yet set up your voicemail, callers cannot leave a message. For help setting up voicemail, see [page 15](#).

## Setting missed call alerts

You can set an alert to beep every five minutes after you have missed a call.

- Select **Menu** → **Settings** → **Sounds** → **Missed Call** → **Enabled**.

- To turn off the alert when it rings, press  or .
- To cancel the alert, select **Menu** → **Settings** → **Sounds** → **Missed Call** → **Disabled**.

## Viewing recent call details

Details on the last 29 calls you made or received are stored in the Recent Calls list. Icons indicate the types of calls in the list.



Outgoing call



Missed call  
(flashing)



Incoming call

## Viewing recent calls



Select **Menu** → **Recent Calls**.

1. Select **All Calls**, **Incoming Calls**, **Outgoing Calls**, or **Missed Calls**.
2. Select a recent call item.
3. Select an option:
  - **Number**—Show the caller’s number (for an incoming call), or the number you called (for an outgoing call).

- **Prepend**—Place the cursor at the beginning of the phone number so you can add an area code.
- **Save New**—Save the phone number as a contact.
- **Add to**—Add the phone number to a saved contact.
- **View Contact**—Show details on the contact if the caller's information is already in your Contacts directory.

**Note:** If the number has been saved as “secret,” you must enter your four-digit lock code to view or edit it. For information on the lock code, see [“Changing your lock code” on page 44](#). To classify a phone number as secret, see [“Saving a contact entry” on page 34](#).

## Erasing recent calls


1. **Menu** → **Recent Calls** → **Erase Lists**.
2. Select an option: **Incoming Calls**, **Outgoing Calls**, **Missed Calls**, or **Erase All**.
3. Press  right and press  to select **Yes**.

## Speed dialing

Speed dialing allows you to quickly dial a stored phone number by entering a one- or two-digit speed


dialing location. You can speed dial a number once you have saved it as a contact and assigned a speed dial number to it. (See [“Saving a contact entry” on page 34](#) and [“Editing or erasing a contact” on page 36](#).)

## Using speed dialing



From the main screen, enter the one- or two-digit speed dialing location assigned to the contact and press .

## Setting up 1-Touch Dialing




1-Touch Dialing is a form of speed dialing that allows you to press and hold a speed dial location to make a call. It is the fastest way to speed dial.

1. Select **Menu** → **Settings** → **Convenience** → **1-Touch Dialing** → **Enabled**.
2. Press .

## Using 1-Touch Dialing


To dial a phone number, simply press and hold the assigned speed dialing location for the phone number. If it is a two-digit location, press the first digit, then press and hold the second. For example, if the speed dialing location is 15, press , then press and hold .

## Removing a speed dialing location

1. Select **Menu** → **Contacts** → **Speed Dial List**.
2. Select a speed dialing location.
3. Select the phone number and press .
4. Select **Speed Dialing**.
5. Select the number to remove.
6. Press  right to select **Remove**.
7. Press .


## Setting up voicemail

Before you can listen to voicemail messages, you must set up a password and record a personal greeting with Virgin Mobile. When you have set up your voicemail, all unanswered calls to your phone are automatically transferred to voicemail, even if your phone is in use or turned off.


1. From the main screen, press and hold .
2. Enter your passcode, which you obtain from Virgin Mobile.
3. Follow the system prompts to create a password and record a greeting.

**Note:** If you are having trouble accessing your voicemail, contact Virgin Mobile.


## Checking voicemail messages

When a voice message is received, your screen will display a notification: “New Message 1 Voicemail.” This text will remain for about five minutes. The  symbol flashes if the message is urgent.

### If you see “New Message” on your screen



1. Press  to select **Voice**. This initiates a call to your voicemail number.
2. Follow the prompts to retrieve the message. For specific information on getting voicemail messages, contact your service provider.

### If you see the symbol

1. Press  to initiate a call to your voicemail number.
2. Follow the prompts to retrieve the message.

**Note:** You can set the phone to beep and/or light up every five minutes to remind you that you have voicemail. For more information, see [“Setting message alerts” on page 46](#).




## Silencing an incoming call

To silence an incoming call quickly, press . Then press  to answer the call.



This action silences the current call only. The next call will ring as normal.

## Using the speakerphone

You can turn the speakerphone on at any time.

- To turn the speakerphone on, press .
- To answer an incoming call and turn speakerphone on at the same time, press .
- To turn speakerphone off, press .

## Making calls using a headset

If you are using a headset equipped with a button, press the button to answer or end a call. If the headset has no button, press  to answer a call and press  to end it. Headsets are sold separately.


## 4 ENTERING LETTERS, NUMBERS, AND SYMBOLS

---

You may enter letters, numbers, and symbols in contacts, text messages, and other functions; for example, when you create a personal banner for your phone's main screen.

### Understanding text entry screens

The current text entry mode (and capitalization setting, when applicable) are indicated by icons.



### Text entry modes

There are five text entry modes:

**A>a** Case Change mode

a<sub>b</sub>c Normal Alpha mode

ezi Rapid Entry mode

1<sub>23</sub> Numbers Only mode

&?! Symbols mode

**Note:** The mode you start in depends on the task you are doing. For example, when entering a phone number, you're in number mode. When entering a name for a contact, you're in normal text mode.

See [“Changing modes” on page 18](#).

### Entering numbers


You can enter numbers in several modes.

- To enter a number while in 1<sub>23</sub> mode, press a number key once.
- To enter a number while in a<sub>b</sub>c or ezi mode, press and hold a number key until the number appears on the screen.

### a<sub>b</sub>c Entering words letter by letter

Use normal text mode to enter letters.

1. Press a key once for the first letter on that key, twice for the second letter, and so on.
2. When the cursor moves right, enter the next letter.



3. To enter a space, press the  key.

## Entering words quickly


When you press a series of keys using **ezi** mode, **ezi** checks its dictionary of common words and guesses at the word you are trying to spell.

1. For each letter of the word you want, press the key once. For example, to enter the word “any” press:

 →  → .

2. If the word doesn't match what you want, press  to look at other word matches.
3. When you see the word you want, press .



## &?! Entering symbols



While entering text, you can also enter symbols by pressing  until you see the symbol you want. This method provides access to the following symbols:

. @ ? ! - , & : ' "

You can also access the full set of symbols:



- . & ' ( ) ¶ ! ? \* #  
% " : + < > = ¡ ¢ £ ¤ ¥ ¦ § ¨ © ª « ¬ ® ¯ ° ± ² ³ ´ µ ¶ · ¸ ¹ º » ¼ ½ ¾  
@ , ~ { } \$ [ ] ^ \_ ; -



1. Press  right to select the current mode and press  to enter the menu.


2. Select **&?! Symbols**.
3. Press  down to view the list of symbols.
4. Press the number key corresponding to the symbol you want, or press  to return to text entry without entering any symbol.

## Changing modes

To enter characters that belong to a mode other than the one you're in, you'll need to change modes. For example, to enter numbers in an email address while in **a<sub>b</sub>c** mode, change to **123** mode, enter the number, and then change back to **a<sub>b</sub>c** mode to complete the address.

**To change text entry modes**, press  right or left to select text entry mode and press  to enter the Text Mode menu. For a list of text entry modes, see [page 17](#).

**To change capitalization**, press  right or left to select text entry mode and press  until the icon for the mode you want appears. Three capitalization settings are available in **a<sub>b</sub>c** and **ezi** modes:











 Capitalize first letter of every *word* (in a contact) or *sentence* (in a text message)

**a** Enter text in lower case only

**A** Capitalize every letter

## Quick reference to text entry

This table summarizes how to enter letters, numbers, and symbols.

To...	Do this...
Enter a letter	Use a <sub>b</sub> c mode and press a key until you see the letter you want.
Enter a number	Use 1 <sub>2</sub> 3 mode and press a key once to enter its number.
Enter a symbol	Use a <sub>b</sub> c mode and press  until you find the symbol you want.
Enter a space	Press  .
Erase a character	Press  .
Erase all characters	Press and hold  .
Move the cursor right or left	Press  up or down.
Change text entry modes	Press and hold  .
Capitalize every letter	In a <sub>b</sub> c mode, press  . Choose <b>A</b> .
Capitalize the first letter	In a <sub>b</sub> c mode, press  . Choose <b>Ⓐ</b> .
Enter text in lower case only	In a <sub>b</sub> c mode, press  . Choose <b>a</b> .
Select an option at the bottom of the screen	Press  left or right.

## 5 SENDING AND RECEIVING TEXT MESSAGES

---

This chapter describes how to send, receive, and erase text messages from your phone. For information on voicemail messages, see [page 15](#).

**Important:** Usage charges may apply. For information regarding these charges, contact [virginmobileusa.com](http://virginmobileusa.com).

### Sending text messages


You can only send text messages to phones that are capable of receiving them, or to email addresses.

### Writing a message



To send a plain text message to a single recipient:

1. Select **Menu** → **Messaging** → **Send Text**.
2. Choose a method to enter the recipient's phone number or email address:
  - Select a saved number from the **Recent List** or **Contacts List** or select a **Group List** you have created. For more about group lists, see [page 25](#).


-or-

- Enter a **New Address** manually.  
(To learn how to enter text, see [page 17](#).)
3. To add another recipient to this message, choose a method:
    - Press  right to select **Options**. Then select **Recent List**, **Contacts**, or **Group Lists**.
    - Enter a space or comma after the first number. Then enter another recipient manually.

**Note:** You can send a message to up to 10 contacts at once. The messages will be sent one at a time, once to each addressee.




4. When you have finished entering addresses, press  right to select **Next** and press .
5. Enter the message. To learn how to enter text, see [page 17](#). To add emoticons, such as smiley faces, see “[Including emoticons and prewritten text](#)” on [page 21](#).

**Important:** When you start a message, the maximum character limit is displayed. This number counts down as you enter characters, until it reaches 0.

6. When you have completed the message, press  to select **Send**.



## Including emoticons and prewritten text



You can include emoticons and AutoText in your text messages.

1. Create a text message and enter addresses (see [page 20](#)).
2. Select **Next** to advance to the messaging text entry screen.
3. From the text entry screen, press  right twice, select **Options** → **Insert** and select from the available options:
  - **Emoticons**—Select a smiley face icon by pressing the key corresponding to the desired icon's number. If the recipient's phone does not support the same technology as your phone, the icons will appear to them in a simplified form.
  - **AutoText**—Select a prewritten message. Select one from the list and press  to select **Insert**. (To edit or create new prewritten messages, see [page 25](#).)
4. When you have completed the message, you can send it immediately or set sending options. To send it immediately, select **Send** and press . To set sending options, see the following procedure.

## Setting sending options

When you are ready to send a message, you have several options for how and when you want the message to be received.


1. Once you have completed the message, press  right to select **Options** and press . Then choose from the list:
  - **Insert**—Enhance your message with smiley faces and prewritten text. See options above.
  - **Add Address**—Return to the “To” screen to add another recipient without losing the message text. Enter the new address, then select **Next** to return to the messaging entry screen.
  - **Save Message**—Save the message in your **Saved** folder. This prevents the message from being deleted if you have activated AutoErase, and enables you to send the message to others.
  - **Save AutoText**—Save the message you have just entered as AutoText, which you can insert into other messages; then return to the messaging entry screen so you can send the message.

2. When you have finished setting options, press  to return to the messaging window.
3. Select **Send** and press .

## Adding a signature

This setting allows you to create signature text. The signature does not display in the message creation screen; however, the signature is included at the end of all outgoing messages.

To create a signature:


1. Select **Menu** → **Settings** → **Msg Settings** → **Signature**.
2. Enter your signature in the text field.
3. Press  to save the setting.

**Note:** The signature text is tallied by the character counter because the signature is included in the text field. See [page 20](#).

## If you cannot send messages


You may not be able to send or receive messages if your phone's memory is nearly full, or if service is not available at the time. To free up memory, erase old messages. See [“Erasing messages” on page 24](#).

## Receiving incoming calls while creating messages

- If you don't wish to answer the call, select **Ignore**.
- To answer the call, press . The message you were working on will be saved in the **Saved** folder. To return to the message, select **Menu** → **Messages** → **Saved** and select it.

## Viewing the OutBox

You can check the status of messages you have sent as long as they have been saved to the OutBox.

1. Select **Menu** → **Messaging** → **OutBox**.
2. Press  up or down through the list of messages. One of the following symbols appears next to each message:



The message is pending and will be sent when possible. You can cancel delivery of the message.



The message cannot be sent because service is not available. An alert appears on your phone if the message cannot be sent.




The message has been sent. You cannot cancel delivery.

---

---

The message has been received by the recipient you specified.

---


 The message has been sent to more than one recipient.

---

The message has never been sent, or has not been sent since it was last modified. You can cancel delivery of the message.





---

## Retrieving text messages


When a text message is received, your screen will display an alert: “New Messages 1 Text Msg(s)”. This alert will remain for about five minutes. After that, look for the  symbol at the top of your screen. The symbol flashes if the message is urgent.

### If you see the “New Messages” alert

You can choose to:

- **View** the message—Press .
- **Ignore** the message—Press  right and press .
- **Clear the screen**—Press .



### If you see the symbol

If the  symbol is flashing, the message is urgent.


1. Select **Menu** → **Messaging** → **InBox**.

A list of all your received messages appears.

New, unread messages appear in *italics*.

2. Press  up or down to scroll through the list of messages.
3. Press  to read a message.

## Reading the message

1. If the text message is long, press  down to view the entire message.

**Note:** Message length is limited by your service provider. An incoming message that exceeds the limit may be truncated.

2. When you are finished, you can **Reply** to the sender, **Erase** the message, **Save** the message to your Saved folder, or set additional **Options** for the message:
  - View **Sender** information.
  - **Forward** the message.
  - **Reply with Copy** to reply to the message with a copy of the original attached.
  - **Save Contact** to save the sender’s phone number or email address in your Contacts list.

(This option is available if a vCard is included in the message.)

- **Save as AutoText** to save the message as AutoText, which you can insert into other messages. (For more about AutoText, see [page 25](#).)

3. Select **Done**.

## Setting message alerts

You can set your phone to alert you of incoming text messages or pages. For more information, see [“Setting message alerts” on page 46](#).




## Erasing messages

Your phone is designed to store 99 text messages and pages. It is a good idea to erase old messages, as messages take up memory in your phone.



You have the option of erasing text messages and pages as you send or read them, erasing them one-at-a-time from the list in the OutBox or InBox, or erasing them all at once.

## Erasing single messages

1. Select **Menu** → **Messages**.



2. Press  down and press  to select the type of text message you want to erase (**InBox**, **OutBox**, or **Saved**).
3. Press  to select the message to erase.
4. Select **Erase** to erase the message. A notification appears: “Erase this message?”
5. Select **Yes** to erase the message.

## Erasing all messages

1. Select **Menu** → **Messaging** → **Erase Msgs**.
2. Press  up or down and press  to select an option:
  - **InBox** erases all messages in your InBox.
  - **OutBox** erases all messages in your OutBox.
  - **Saved Folder** erases all messages in your Saved folder.
  - **All Messages** erases all text messages in all folders listed above.
3. A message appears: “Erase all messages?” Select **Yes** to erase messages or **No** to cancel.

## Erasing messages automatically

Use this setting to have old messages automatically erased from the InBox when memory is low.



1. Select **Menu** → **Messaging** → **Msg Settings** → **Auto-Erase**.
2. Press  down and press  to select **Old InBox** text.



## Customizing message settings

To make messaging easier, you can customize settings for sending and receiving messages.





### Creating group lists

You can create and save a list of multiple recipients. Your Slider V5 phone will store five group lists with up to 10 recipients per list.

1. Select **Menu** → **Messaging** → **Group Lists** → **Create New**.
2. Enter a name for the list. For help entering text, see [page 17](#).
3. Press  to select **Next**.
4. To enter the first phone number or email address, select an option:
  - **Recent List**—Select numbers from your Recent List. Select the number or contact name and press . The phone number appears in the address field.

- **New Address**—Enter the phone number or email address yourself. To enter letters, press  to switch to **abc** mode. To enter symbols, press  until you find the symbol you want. For more information on text entry modes, see [page 17](#).

-or-

- **Contacts List**—Select contacts from your phone book. Select the contact and press  twice. The phone number appears in the address field.
5. To enter the next address, enter a space or comma after the first number or email address. (If you insert a saved contact or a number from the Recent List, the phone will insert the comma automatically.) Then press  right twice, select **Options**, and choose from the options.
  6. Press  right and press  to select **Done**.
  7. To send a message to your new group, see [“Sending text messages” on page 20](#).

### Creating and editing prewritten messages (AutoText)

Your phone comes with prewritten (AutoText) messages, such as “What’s up?” which you can insert

into the body of a text message. You can edit these messages and create new ones. Your phone will store up to 20 additional AutoText messages, with up to 100 characters per message.

1. Select **Menu** → **Messaging** → **Msg Settings** → **Edit AutoText**.
2. To create a new pre-written message, select **New AutoText** and press **OK**.

-or-

To edit an existing pre-written message, select the message and press **OK**.

3. Enter or edit the text and press **OK** to select **Done**.  
For help entering text, see [page 17](#).

**Note:** You can also save a message you are writing or an incoming message as AutoText. For directions, see [page 21](#) and [page 24](#).

### Accessing VirginXtras

With VirginXtras, you can access a variety of exclusive music, entertainment, and information services from your Slider V5 phone. You can find popular features such as Ringtones, Rescue Rings, and Wake-Up Calls. Get \*MTV music news, answer opinion polls, check show listings, and more.

There are many VirginXtras to explore and new VirginXtras are added all the time. Check Virgin Mobile's Web site at [www.virginmobileusa.com](http://www.virginmobileusa.com) for availability and pricing.

### To access VirginXtras






Select **Menu** → **VirginXtras**.

**Note:** You cannot receive incoming calls during a VirginXtras session. All incoming calls are automatically sent to your voicemail.

### To end a VirginXtras session

Press .

### Navigating VirginXtras

- Press  to select the item and press  to select a VirginXtras menu item or option.
- Press  to go back one screen.
- A scroll bar on the right side of the screen indicates that there is more text. Press  down to go to the next screen of text. Press  to move back one screen.

## 7 \*MTV

---

\*MTV (that's the wireless part of MTV) brings MTV right to your new phone. You can get alerts about your favorite shows, see the latest MTV News, interact with MTV community members, play games, and much more.

### Accessing \*MTV

To check out all of the \*MTV content, go to \*MTV in the VirginXtras menu, or just select **Menu** → \*MTV.

Also, go to [www.mtv.com/starmtv](http://www.mtv.com/starmtv) to find out about all of the latest stuff.





## 8 GAMES

---

Your Slider v5 phone comes with games and a doodler. If you receive an incoming call alert while you are playing Tetris<sup>®</sup>, Brick Attack<sup>™</sup>, or Race 21<sup>™</sup>, the game is paused and exited. You can return to play once the call alert ends. Games do not remain paused if the phone is turned off or loses power.

### Tetris

The goal of this game is to guide the falling blocks down the screen to create a solid horizontal row at the bottom. Each time a row is completed, it disappears and the remaining blocks move down one row. The game ends when the new block cannot enter the play field because the area is occupied by another block or obstacle.

1. Select **Menu** → **Games** → **Tetris**.
2. If you wish to conserve battery power while playing the game, select **Yes** at the prompt, “Dim backlight to conserve battery?”
3. Select an option and press  to select it.
  - **New Game**—Initiates game play. To pause the game, press  or . Pressing  returns you to the menu where you can **Continue Game** to resume or choose from the other available options.
  - **Resume Saved**—Returns you to the game you were last playing.
  - **Scoreboards**—Displays the top five scores for the different game variations, including **No Time Limit** (default), **Timed 2 Min**, **Timed 3 Min**, **Timed 5 Min.**, and **Garbage**.
  - **Settings**—Choose various settings for your Tetris game:
    - **Game Type**—Choose type of game.
    - **Music**—Choose when theme music will play with this game: **Music Always**, **During Title**, or **No Music**. (The **No Music** setting does not silence the sounds made when you press keys. To silence keys, see “[Silencing all sounds](#)” on page 40.)
    - **Next Piece**—Choose whether to show the next piece that will fall.
    - **Sound Effects**—Choose to hear sound effects while playing the game.
    - **Starting level**—Choose a level of play.

**Navigation:** Use the following keys to guide the blocks down the screen:

To:	Use:
Rotate Counterclockwise	,  , or
Hard drop	
Move left	or  left
Rotate Clockwise	,  ,  up,  , or
Move right	or  right
Soft drop the tile	or  down
Return to Tetris menu	
Pause	

## Brick Attack

The goal of this game is to eliminate bricks arranged in levels. To do this, you send a moving ball upward using a paddle at the bottom of the screen.

1. Select **Menu** → **Games** → **Brick Attack**.
2. If you wish to conserve battery power while playing the game, select **Yes** at the prompt, “Dim backlight to conserve battery?”

3. Press to select **New**.
  - To pause the game, press , then press to **Resume**.
  - To move the paddle, press left or right.To exit the game, select **Exit** and press .


## Race 21


This game is a timed variation of Blackjack. Each game comprises three 90-second rounds. To score points, add cards in each of the four columns, trying to reach but not exceed 21 within each column during the course of the game.


To play:

1. Select **Menu** → **Games** → **Race 21**.
2. Press to select **Yes** at the prompt, “Dim backlight to conserve battery?”
3. Select **New Game**. The first card to be placed is shown at the top left of the screen. Press a key to add a card to the row as follows:




- Add cards to the first row
- Add cards to the second row
- Add cards to the third row




 Add cards to the fourth row

**Shortcut:** Press  left or right to choose arrows at the bottom of the screen.

Then press  to add cards to corresponding rows.


**Note:** Each time you place a card, it is replaced with a new one to be placed into a row.

- Continue placing cards until you are satisfied with your selections.
  - You can pause or end the game at any time by pressing .
  - You lose points each time you exceed 21 in a column.
  - Remember, there is a time limit!
  - Select **Skip** to skip one card per round.
- Press  to select  to take your score and advance to the next round.


- Select an option and press  to select it.
  - New Game**—Initiates game play. To pause the game, press . From here you can choose **Resume**, **New**, **Save**, or **Quit**.
  - Resume Game**—Returns you to the game you were last playing.
  - Scoreboard**—Provides you with the top five scores.
  - Music**—Choose when you hear theme music with this game. Select from **Music Always**, **During Title**, or **No Music**.
- Press  to end all games.

## **Doodler**

Doodler™ allows you to create and manipulate images, import shapes, and save images as screen savers.

- Select **Menu** → **Games** → **Doodler**.
- Wait 5 seconds for the intro screen to disappear, or press  to clear it.


3. Select **New Doodle** to open the drawing screen. You will see a flashing cursor in the middle of the screen:



The selected tool is highlighted in yellow. By default, the selected tool is “draw black.”




4. Use keys 1–9 to move the cursor around the screen as indicated.

**Note:** Press **(S)** to bring the cursor back to center.



## Using the Doodler toolbar

To change between the tools on the toolbar, select the desired tool.

-  draw (in the color shown)
-  move cursor
-  eraser


**Tip:** For a shortcut to the Move feature, press **(M)**.

## Modifying the doodle

To modify your doodle, press **(C)** right or left to select an option at the bottom of the screen:


- **Color**—Select to change the color of the cursor (the line you’re drawing).
- **Add Shape**—Select an existing shape such as a circle and re-size, rotate, or move it. Select **Done** when finished.
- **Size**—Enlarge or shrink a defined shape by pressing **(O)** repeatedly.
- **Rotate**—Change the position in 90-degree increments.
- **Move**—Move the image around the screen using keys 1–9.

- **Clear**—Clear the entire screen.

**Tip:** The shortcut to this feature is .

## Saving the doodle

It is a good idea to save the doodle while you are working on it. If you receive a call while creating an unsaved doodle, it will be lost.

- Select **Save** and press .

## Resuming a doodle

To return to the last saved doodle you were working on, select **Menu** → **Games** → **Doodler** → **Resume Doodle**.

## \* MTV Games


Waste time and love it with exclusive music and pop culture games from \*MTV.

Select **Menu** → **Games** → **\*MTV Games** or go to [www.mtv.com/starmtv](http://www.mtv.com/starmtv) to find out more about the latest available games.

## 9 STORING CONTACTS

---

Use your phone's Contacts directory like a set of phone index cards to store information about a person or company. Your phone can 200 contact entries.

**Tip:** From the main screen, press  to select **Contacts**.



### Saving a contact entry

To save a phone number or pager number, take these steps.




1. From the main screen, enter the phone number you want to save.

**Tip:** Enter the area code with the phone number so that you can dial it from any service area.


**Note:** To save a contact without entering a phone number, select **Menu** → **Contacts** → **Add New**. Select an option and skip to step 3.

2. Press  to select **Save New**.
3. Enter a name for the contact. If you need to learn how to enter letters, see [page 17](#).
4. Either save the contact now or assign options. To save now, press  to select **Save**.

-or-





To assign options, press  right, then press  to select **Options**. Press  up or down to select from the list:

- **Save**—Save the information and return to the main screen.
- **Assign Ringtone**—Select a Ringtone to identify an incoming call from this contact.
- **Unassign Ringtone**—Remove the Ringtone.
- **Assign Caller ID Cartoon**—Select one of over 20 pictures to identify an incoming call from this contact.
- **Unassign Caller ID Cartoon**—Remove the picture.
- **Number Type**—Select **work**, **home**, **mobile**, **pager**, or **fax**. The number type will appear as an icon next to the number in the Contacts list.
- **Add Voice Dial**—Speak the name of the contact person for this number so that you can dial it using voice recognition (VR). For more information, see [page 48](#).
- **Speed Dialing**—Select a speed dialing location from the list.

- **Secret**—Select **Yes** to lock the phone number. If a phone number is locked, you must enter your four-digit lock code (see [page 44](#)) to view or edit the number.
  - **Primary Number**—Classify this number as the primary number for the contact.
  - **Classify Contact**—Classify the contact as **Personal** or **Business**. (See [page 41](#) to set the phone to ring differently for personal and business calls.)
5. Press  to select **Save**. A check mark and the text “Contact Successfully saved!” appear.



## Adding a code or extension

When you save the phone number of an automated service (bank, voicemail system, etc.), you may include a pause where your phone should stop dialing. For example, if you wish to dial a phone number followed by an extension, a pause should be placed before the extension.

1. Enter the first portion of the phone number.
  2. Press  right to scroll through the options at the bottom of the screen.
  3. Press  to select a type of pause.
-  A **Time Pause**—Stops dialing for two seconds, then continues to dial.
  -  A **Hard Pause**—Stops dialing until you select **Release**.
4. Enter the remaining numbers.
  5. Select **Save New**.

## Saving an email address, street address, URL, or note

To save an email address, street address, Web page URL, or note as a *new* contact, follow these steps. To add one of these items to a saved contact, see “[Editing or erasing a contact](#)”

1. Select **Menu** → **Contacts** → **Add New**.
  - Highlight **Phone Number**, **Email Address**, **Street Address**, **URL**, or **Note** and press  to select it.
2. Enter the information. (Tip: To enter symbols, press and release . Repeat to cycle through symbols.)
3. Select **OK**.
4. Enter a contact name.
5. Select **Save**.

## Editing or erasing a contact

To make changes to a contact, take these steps.  
(To erase all saved contacts, see [page 46](#).)

1. Select **Menu** → **Contacts**.
2. Select **View All** or **Find Name** to find the contact you want to edit.
3. Highlight the contact to edit and press **OK**.
4. Select **Options**.
5. Highlight an option and press **OK** to select it:
  - **Add New** to add a phone number, email address, street address, Web page URL, or note to the existing contact.
  - **Assign Ringer** or **Unassign Ringer** to select or remove a ringer to identify an incoming call from this contact.
  - **Assign Picture** or **Unassign Picture** to select or remove a picture to identify an incoming call from this contact.
  - **Erase Contact** to erase the entire contact.
  - **Edit Name** of the contact.
  - **Classify Contact** as personal or business.
6. Enter the new information.
7. Press **OK** to select **Save**.

## Editing a phone number

1. Select **Menu** → **Contacts**.
2. Select **View All** or **Find Name** to find the contact you want to edit.
3. Highlight the contact to edit and press **OK**.
4. Press **Down Arrow** to highlight the phone number you want to edit and press **OK**.
5. Highlight an option for the phone number and press **OK**:
  - **Send Text Msg**—Send a text message to the phone number you selected.
  - **View Number**—See the phone number you selected.
  - **Add Voice Dial**—Speak the name of the contact person for this number so that you can dial it using voice recognition (VR). For more information, see [page 48](#)
  - **Speed Dialing**—Select a location that you can use to speed dial the number.
  - **Edit Type**—Assign a type: **work**, **home**, **mobile**, **pager**, or **fax**. The type icon appears next to the phone number in the Contacts list.
  - **Erase Number**—Erase the number from the contact.

- **Erase Voice Dial**—Erase the voice dial name associated with the number.
- **Edit Number**—Change the phone number.
- **Edit Voice Dial**—Record a new voice dial name.
- **Secret**—Make the number secret, so that when someone opens the contact, the phone number will not appear until the lock code is entered. Secret numbers can be called, however, without a lock code. (For more information, see “[Restricting calls](#)” on [page 45](#).)
- **Primary Number**—Make this number the first one that shows up when you open the contact.
- **Prepend**—Move the cursor to the beginning of the number so you can add the area code.
- **Exit**—Exit without making changes.


6. Enter the new information and follow the prompts.

7. Press **OK** to select **Save**, if necessary.

## Finding contact information

To find a phone number or contact, either (1) check the frequent contacts list, (2) search the Contacts directory, or (3) use Fast Find.

## Checking the Frequent List or the All Contacts List

From the main screen, press  to see the last 15 of your most frequently called contacts. Note that you must enable this feature.



### To enable the Frequent List setting

1. Select **Menu** → **Settings** → **Convenience** → **Frequent List**.
2. Select **Enabled**.

**Tip:** You can enter the first letter of the name you are looking for to skip down the list.

### Searching the Contacts directory

1. Select **Menu** → **Contacts**.
2. Select a search method:
  - **View All**—List all saved contacts.
  - **Find Name**—Locate a specific name. Enter part of the contact name, then select **Find**.
  - **Speed Dial List, Voice Dial List, Business List, or Personal List**—Select a contact from a list.
3. Scroll down until you find the name you want, then press **OK**.

- To call the contact, select the number and press .
- To display the full contact, press .




## Setting Fast Find

With Fast Find enabled, you press one or two keys to view close matches of the number you are looking for.

1. From the main screen, select **Menu** → **Settings** → **Convenience** → **Fast Find**.
2. Select **Enabled**.

When you use Fast Find, speed dial locations appear before names if they use the same keys.

## Using Fast Find

1. From the main screen, press the keys corresponding to the letters of the name you want to find. A matching contact or speed dial entry appears. Press  down to scroll through matching entries.
2. View the name you want, then press  to call the number or press  to view contact details.

## Viewing contacts

The following icons may appear next to information in your Contact entries.



work



email address



home



street address



mobile



Web page URL



pager



Note



fax

## 10 CUSTOMIZING YOUR PHONE

---

The contents of the **Settings** menu are as follows.

### **Silent Mode**

Vibrate Only  
Vibe then Ring  
Lights Only  
Normal Sounds

### **Sounds**

Ringtone Volume  
Ringtone  
Slide Open  
Slide Close  
My Ringtones  
Business Ring  
Personal Ring  
Earpiece Volume  
Key Volume  
Key Length  
Missed Call Alert  
Smart Sound  
Minute Alert

### **Display**

Backlighting  
My Banner  
Main Menu View  
Screen Saver  
Wallpaper  
Color Themes  
Auto-Hyphen  
Time Format  
Contrast

### **Voice Services**

Add Voice Dial  
Erase Voice Dial  
Voice Training  
Voice Wake-Up  
Voice Answer  
Expert Mode

### **Security**

Lock Phone  
Limit Calls  
Lock Code  
Erase Contacts  
Emergency #'s

### **Call Information**

Recent Calls Timer  
All Calls Timer

### **Network**

Privacy Alert  
Location

### **Convenience**

Airplane Mode  
Fast Find  
Frequent List  
Hold Call  
1-Touch Dialing  
Open to Answer

### **Msg Settings**

Voicemail Num.  
Alerts  
Signature  
Edit AutoText  
Callback Number  
Save to Outbox  
Auto-Erase  
Default Text

### **Accessories**



Pwr Backlight  
Headset Ring  
Auto-Answer  
Close to END

## Silencing all sounds

Your phone is set to make sounds when you receive calls, press keys, navigate through menus, and receive alerts (such as new messages).



You can silence all sounds and set the phone to vibrate or light up when you receive calls and alerts.

### Setting the phone to vibrate or light up

1. Select **Menu** → **Settings** → **Silent Mode**.
2. Choose an option and press :
  - **Vibrate Only**—Causes the phone to vibrate for the duration of the incoming call or other alert.
  - **Vibrate, Ring**—Causes the phone to vibrate for the first 10 seconds and then ring for the remainder of the incoming call alert.
  - **Lights Only**—Causes the screen and keys to light up and flash for the duration of the incoming call or other alert.
3. Press  to return to the main screen.




**Note:** The phone will ring when attached to an external power source (such as a charger), even if Silent Mode has been activated.

### Shortcut to Vibrate Only mode

- From the main screen, press  right and hold.  
-or-
- Press  and hold.


### Turning sounds back on

To restore all sounds to the phone:

- From the main screen, press  right and hold.  
-or-
- If in Vibrate Only mode, press  and hold.  
-or-
- Use menus:
  - a. Select **Menu** → **Settings** → **Silent Mode**.
  - b. Select **Normal Sounds**.
  - c. Press  to save your selection.

## Choosing a different Ringtone

Your Slider V5 phone comes with 15 pre-loaded Ringtones you can choose to use for incoming calls. To choose a Ringtone:

1. Select **Menu** → **Settings** → **Sounds** → **Ringtone**.
2. Scroll down the list to hear each Ringtone.
3. Press  to select a Ringtone from the list.

You can download up to 10 additional Ringtones to your phone. Find hundreds to choose from at [www.virginmobileusa.com](http://www.virginmobileusa.com). Check with Virgin Mobile for any charges that may apply.

**Note:** After downloading a Ringtone to the list on your phone, you still need to choose it as the one you want to hear.

## Specifying Ringtones for different callers

You can assign Ringtones that identify calls from different phone numbers saved in your Contacts directory.


- To assign a Ringtone to an individual contact, see [page 34](#).
- To assign a Ringtone to a class of contacts:
  - a. Select **Menu** → **Settings** → **Sounds**.
  - b. Highlight **Business Ring** or **Personal Ring** and press **OK**.
  - c. Select a Ringtone and press **OK**.

**Note:** To classify a contact as business or personal, see [page 35](#).


## Adjusting volume

You can adjust the volume of the earpiece, the ringer, the speakerphone, or the beeps you hear when the keys are pressed.

### Adjusting the earpiece volume

To adjust the earpiece volume manually during a call, press  up or down to find a comfortable level.

### Adjusting the ringer volume

1. Select **Menu** → **Settings** → **Sounds** → **Ringer Volume**.
2. Press  right to increase the volume, or left to decrease the volume.

The ringer volume also adjusts the volume levels for the Countdown Timer, Scheduler Alert, and Alarm Clock.

### Changing the key tones

You can change the volume and duration of the tones the phone makes when you press the keys. Select **Menu** → **Settings** → **Sounds** and choose **Key Volume** or **Key Length**.

## Using shortcuts



From the main screen, you can access shortcuts by pressing the navigation key in different directions.

Four shortcuts to features of your phone have been programmed into it. (Left accesses VirginXtras. Right silences all sounds. Down accesses your recent calls. Up initiates a balance query.)

## Personalizing the screen

### Changing your banner

The banner is the personal label for your phone. It appears on the main screen above the time and date. The banner can be up to 14 characters long.



1. Select **Menu** → **Settings** → **Display** → **My Banner**.
2. Select **Edit**.
3. Press  to clear the screen.
4. Enter your new text. (To learn how to enter text, see [page 17](#).)
5. Press  to save.

## Selecting a screen saver

Screen savers work only from the main screen, and they are activated 10 seconds after the last keypress. Incoming calls and alerts override screen savers.


**Note:** Voice services will not work when a screen saver is activated.

To activate a screen saver:

1. Select **Menu** → **Settings** → **Display** → **Screen Saver**.
2. Select one of eight animated screen saver names and press .
3. Press  to return to the main screen and wait 10 seconds to view the screen saver you chose.

**Note:** You can add graphics you have created or saved to the Screen Saver List. Refer to [page 31](#).

## Choosing a different time/date format

1. Select **Menu** → **Settings** → **Display** → **Time Format**.
2. Highlight the option you want and press .

## Choosing a different menu view

You can change the appearance of the menus you see when you select **Menu** from the main screen.

1. Select **Menu** → **Settings** → **Display** → **Main Menu View**, then the option you want:



**Graphic**



**List**

2. Press to return to the main screen. The next time you press , you will see the menu view you selected.

## Adjusting the backlighting

Your screen lights up while you are in a call or when you press a key on the keypad. However, you can change when and how backlighting lights up.

1. Select **Menu** → **Settings** → **Display** → **Backlighting** → **Duration**.
2. Select an option from the list:
  - **Off**—Turns backlighting off.
  - **5 seconds**—(Default) Turns backlighting on for 5 seconds after your last keypress.
  - **10 seconds**—Turns backlighting on for 10 seconds after your last keypress.

- **30 seconds**—Turns backlighting on for 30 seconds after your last keypress.
- **5 sec & in call**—Turns backlighting on during a call, and for 5 seconds after your last keypress.
- **10 sec & in call**—Turns backlighting on during a call, and for 10 seconds after your last keypress.
- **30 sec & in call**—Turns backlighting on during a call, and for 30 seconds after your last keypress.

**Note:** Keeping backlighting on during a call drains the battery more quickly and reduces talk and standby times.

## Setting power backlighting

You can set backlighting to remain on when an external power source, such as the AC adapter, is used with the phone.

**Note:** Power backlighting may not be available with some accessories. Check with your service provider.

1. Select **Menu** → **Settings** → **Accessories** → **Pwr Backlight**.

2. Select **Always on** to keep backlighting on.  
(The battery charges more slowly when power backlighting is on.)

## Setting wallpaper

Wallpaper appears on the main screen when the phone is not in use.

1. Select **Menu** → **Settings** → **Display** → **Wallpaper**.
2. Select one of 17 wallpaper designs and press **OK**. Press **OK** again to confirm the assignment.
3. Press **Home** to return to the main screen and view the wallpaper design you chose.

## Setting a color theme

1. Select **Menu** → **Settings** → **Display** → **Color Themes**.
2. Highlight a color theme and press **OK**.

## Changing the display contrast

1. Select **Menu** → **Settings** → **Display** → **Contrast**.
2. Select the level of contrast you want.

## Setting numbers to auto-hyphenate

Auto-hyphenation is a setting that automatically inserts hyphens into your phone numbers to be consistent with the U.S. dialing plan. For example, 1-222-333-4444.

- Select **Menu** → **Settings** → **Display** → **Auto-Hyphen** → **Enabled**.

## Creating a secure environment

This section describes the features involved in securing your phone and preventing access to personal information. All security features are shielded by a four-digit lock code.

## Changing your lock code

The lock code is typically 0000 or the last 4 digits of your phone number.


1. Select **Menu** → **Settings** → **Security**.
2. Enter your four-digit lock code and select **Lock Code**. A message appears: “Change Code?”
3. Select **Yes**, enter a new four-digit code, then press **OK**. Enter your new lock code again.

## Locking your phone

When your phone is locked, you can call only emergency numbers or your service provider number. You can still receive incoming calls.

1. Select **Menu** → **Settings** → **Security**.
2. Enter your four-digit lock code.
3. Select **Lock Phone**.
4. Highlight an option:
  - **Never**—Does not lock the phone.
  - **On power up**—Locks the phone every time you turn it on.
  - **Now**—Locks the phone immediately.
5. Press **OK**.

## Unlocking the phone

1. From the main screen, press  to select **Unlock**.
2. Enter your four-digit lock code.

## Designating emergency numbers

The emergency numbers feature allows you to specify three personal phone numbers that can be called when the phone is locked.

To designate emergency numbers:

1. Select **Menu** → **Settings** → **Security**.
2. Enter your four-digit lock code.
3. Select **Emergency #'s**.
4. Select an **Unassigned** slot.  
**Note:** Enter the phone number, including the area code. Do not enter 1 before the area code.
5. Press **OK** to select **Done**.

### Notes:

- You can view these numbers only when they're being entered for the first time.
- You cannot edit these numbers.

To make a call to an emergency number from a locked phone, you must dial the number (including area code) exactly as it was stored in Emergency Numbers.

## Restricting calls

You can restrict the calls that can be made from your phone to only those that have been saved in your contacts directory.

1. Select **Menu** → **Settings** → **Security**.
2. Enter your four-digit lock code.
3. Select **Limit Calls**.
4. Select **Limit Outgoing** and press **OK**.

## Erasing all contacts

You can erase all contacts from the Contacts directory.

1. Select **Menu** → **Settings** → **Security**.
2. Enter your four-digit lock code.
3. Select **Erase Contacts**.
4. Select **Yes** to erase all contacts. A message appears: “Erase ALL contacts?”
5. Select **Yes** to erase all contacts.

## Setting message alerts

You can choose how you want be alerted of incoming voicemail, pages, or text messages.

1. Select **Menu** → **Settings** → **Messaging** → **Alerts**.
2. Select the type of alert: **Message**, **Net**, **Page**, or **Voicemail**.
3. Press **OK** to select an option:
  - **Disabled**—Turns off message alerts.
  - **Vibrate Once**—Sets the phone to vibrate once when a new message is received.
  - **Vibe & Remind**—Sets the phone to vibrate once when a new message is first received, and once every five minutes. To stop the reminder, press **OK** to select **Ignore**.

- **One Soft Beep**—Sets the phone to beep once softly when a message is received.
- **Soft Beeps**—Sets the phone to beep softly approximately every five minutes. To stop this reminder, press **OK** to select **Ignore**.
- **One Loud Beep**—Sets the phone to beep once loudly when a message is received.
- **Loud Beeps**—Sets the phone to beep loudly approximately every five minutes. To stop this reminder, press **OK** to select **Ignore**.

## Setting alerts for your headset

When a headset (sold separately) is attached to the phone, you can set alerts to originate from the headset.

1. Select **Menu** → **Settings** → **Accessories** → **Headset Ring**.
2. Select **Out of headset** to have alerts originate from the headset.

## Setting position location

This setting allows you to share your location information with network services other than emergency services, such as 911, in markets where service has been implemented.

**Note:** You do not have the option of turning off the locator to emergency services.

To set your option:


1. Select **Menu** → **Settings** → **Network** → **Location**.
2. If you see a message prompt, press **OK** to continue.
3. Select **911 Only** or **Location On**.
  - **911 Only** (default) shares your position information only with emergency services when making a 911 call.
  - **Location On** shares your position information with your service provider's network, in addition to emergency services.

For information on emergency calls, see [“Calling Emergency services”](#) on page 12.

## 11 USING VOICE RECOGNITION

---

Voice recognition allows you to make and answer calls by speaking commands into the phone's microphone.

**Note:** You cannot use voice recognition to end a call; you must press .

### Setting up voice dialing

To make or receive calls using voice recognition (voice dialing), contacts must be saved and have associated voice commands, or *voice tags*.

### Creating a voice tag for a contact



This procedure allows you to record a voice tag before creating a new contact or assigning it to a contact.

1. Select **Menu** → **Contacts** → **Add Voice Dial**.
2. Follow the voice prompts to record a name for the contact.
3. Highlight an option:
  - **Add new**—Save a new contact to go with the voice tag.
  - **Add to existing**—Add the voice tag to a saved contact.


### Viewing entries with voice tags

- Select **Menu** → **Contacts** → **Voice Dial List**.  
A list of all contacts with assigned voice tags appears.

### Editing a voice tag


1. Select **Menu** → **Contacts** → **Voice Dial List**.
2. Highlight the contact you want to edit, and press  to select it.
3. Highlight the phone number and press .
4. Select **Add Voice Dial**, **Edit Voice Dial**, or **Erase Voice Dial**.
5. Follow the prompts.

### Calling using voice tags

1. If you haven't already done so, record a voice tag for the person you wish to call. See [“Setting up voice dialing.”](#)
2. From the main screen, press .  
The phone responds: “Say a name or say Dial.”
3. Say the name of the person you want to call.

4. If the name you said matches a contact in the Voice Dial List, the phone responds: “Calling (Name).” Remain silent to make the call, or say “**No**” to cancel.


**Note:** If there are multiple names saved in the Voice Dial List that match the name you said, you will be asked to verify which name you want to call. Say “**Yes**” when you hear the correct name. Say “**No**” when you hear an incorrect name.

5. When you are finished, press .  
You cannot end the call with a voice command.

## Making calls using digit dialing

When using digit dialing, you speak digits to dial a phone number.

**Note:** You cannot speak a string of digits. You must speak one digit at a time and wait for the prompt.

1. From the main screen, press .  
The phone responds: “Say a name or say Dial.”
2. Say “**Dial**.” The phone responds: “Speak a digit.”
3. Speak the first digit of the phone number you want to call. Once the phone repeats the digit, you can speak the next digit.

If you pause, the phone will prompt you with the following five options. After the prompt, speak an option.

- Say “**Clear**” to erase the digit last entered.  
The phone responds: “Digit cleared.”  
To clear the entire phone number, say “Clear” again. When the phone prompts you with “Clear entire phone number?”, say “Yes” to clear or “No” to cancel.
- Say “**Call**” to dial the number.
- Say “**Verify**” to cause phone to repeat the set of digits that you input.
- Say “**Cancel**” to exit voice recognizer and return to the main screen.
- Speak a digit to enter the next digit. Once the phone repeats the digit, you can speak the next digit or pause to hear the prompt.


## Making calls using expert mode

Expert Mode substitutes tones for some voice prompts to allow the experienced user to quickly complete certain tasks without having to listen/wait for a voice prompt.

To enable Expert Mode:

1. Select **Menu** → **Settings** → **Voice Services** → **Expert Mode**.
2. Select **Expert**.

To make a call in Expert Mode:

1. Press  and wait for the beep.
2. Say the name or the speed dial number of the contact you want to call, or say **“Dial”** and after each beep speak a digit of the phone number.

## Using voice features with accessories

You can use voice commands to make a phone call, answer the phone, or ignore an incoming call only if your phone is connected to an accessory such as a hands-free headset (sold separately).

Accessories for your Slider V5 phone are available at [www.kyocera-wireless.com](http://www.kyocera-wireless.com).

## Waking up the phone

If your phone is connected to a Kyocera hands-free car kit or headset, you can use a voice command to activate the phone to make a phone call.

To activate the Voice Wake-up setting:

- Select **Menu** → **Settings** → **Voice Services** → **Voice Wake-Up** → **With ext. pwr.**

To wake up the phone:

1. Say **“Wake Up”** and listen for a tone.
2. Say **“Wake Up”** again until you hear two tones.

If the phone does not recognize your **“Wake up”** command, see **“Training voice recognition”** on [page 51](#).

## Answering the phone

You can set the hands-free car kit to either (1) answer automatically or (2) ring until you press a key or answer using a voice command.

### Answering automatically

To set it to answer the phone automatically:


1. Select **Menu** → **Settings** → **Accessories** → **Auto-Answer**.
2. Select **After 5 secs.**

### Answering using voice commands

If Auto-Answer is turned off, you can use a voice command to answer an incoming call using a Kyocera hands-free car kit or headset.

1. Select **Menu** → **Settings** → **Accessories** → **Auto-Answer**.
2. Select **Disabled**.

To activate the Voice Answer setting:

1. Make sure the phone is *not* in Silent Mode (see [page 40](#)).
2. Select **Menu** → **Settings** → **Voice Services** → **Voice Answer**.
3. Highlight **Enabled**, then press .


To answer a call:

When you receive an incoming call, the phone responds: “Incoming call, answer?” or “Incoming roam call, answer?” If the caller is recognized as a contact entry in your phone, then the phone will say “Incoming call from (Name), answer?”

- Say “**Yes**” or press any key *except* .


## Ignoring an incoming call

To ignore an incoming call, do one of the following:

- Say “**No**” and press  to silence the alert.
- Remain silent. The voice alert repeats twice and the phone rings once, then returns to the main screen.

## Training voice recognition

If your phone is having trouble recognizing your voice, you can train it with the commands “**Yes**,” “**No**,” and “**Wake up**.”

1. Select **Menu** → **Settings** → **Voice Services**.
2. Select **Voice Training**.
3. Read the message and press .
4. Select **Train All**.
5. Follow the prompts for each word until training is complete.

**Note:** The “Wake up” command can only be used with a hands-free car kit or headset (both sold separately). See [page 50](#).

## 12 USING TOOLS

---

### Voice Memo

The Voice Memo tool allows you to record and play back audio memos.





#### Functions

	Play		Fast forward
	Pause	<b>NAME</b>	Name the memo
	Stop	<b>ERASE</b>	Erase a memo
	Rewind		




#### Recording a voice memo

1. Select **Menu** → **Tools** → **Voice Memo** → **Record New**.



The phone says: “Please record at the tone.”

2. Say your memo and select  when finished.
  - To review your recording, select .
  - To save a name for your memo, press  right and select **Name**. You may enter up to 18 characters. Memos saved without names are identified by date and time.
3. Press  to select **Save**.




#### Playing a voice memo

1. Select **Menu** → **Tools** → **Voice Memo**.
2. Highlight the memo you want to hear.
3. Press .
4. Highlight  and press .




#### Rewind and fast forward

To rewind or fast forward a voice memo while it is playing, select  to rewind or  to fast forward.

#### Naming a saved voice memo

1. Select **Menu** → **Tools** → **Voice Memo**.
2. Highlight the memo and press .
3. Press  right to highlight **Name**.
4. Press  and follow the prompts.











#### Erasing a saved voice memo

1. Select **Menu** → **Tools** → **Voice Memo**.
2. Highlight the memo and press .
3. Press  right to highlight **Erase**.
4. Press  and follow the prompts.







## Scheduler

The Scheduler allows you to schedule events and set reminder alerts.

### Adding an event




1. Select **Menu** → **Tools** → **Scheduler**.
2. Select **Add Event** and press .
3. Enter a name for the event and press . For help entering text, see [page 17](#).
4. Set the event Start time, Duration, and Alarm and press .
  - Press  up or down to select hour, minutes, and timing of alarm.
  - Press  left or right to move between fields.
5. Add a note to the event and press  or press  twice to finish.
6. Set the day and month for the event and press .
  - For a day in this month, select **View Day**. Press  left or right to scroll through days.
  - For a day in a different month, select **View Month**. Press  up or down to scroll through months, and right or left to scroll through days.

### Viewing, editing, or erasing an event

1. Select **Menu** → **Tools** → **Scheduler**.
2. Select **View Day** or **View Month** to find the event you want to view, edit, or erase.
3. Press , down, left, or right to highlight an event and press  to select it.
4. Press  right and press  to select **Edit**, **Erase**, or **New**. Follow the prompts.
5. Press  to return to the main screen or  to return to scheduler options.







### Alarm Clock

Use the Alarm Clock to set an alert for a specific time. The alert occurs only if the phone is on.

1. Select **Menu** → **Tools** → **Alarm Clock** → **Set**.
  - Press  up or down to select an hour and minutes.
  - Press  left or right to switch between hours, minutes, and a.m./p.m.
  - Use the phone keypad to enter numbers.
2. Press  to select **Done** and save the setting.
3. When the alarm rings, select **Off** to turn off the alarm or **Snooze** to silence the alarm for 10 minutes.


## Tip Calculator



The Tip Calculator helps you calculate how much tip to include on a bill.

1. Select **Menu** → **Tools** → **Tip Calculator**.
2. Enter the amount of your bill and press .
3. Select the amount you want to include as a tip (10%, 15%, 18%, 20%, Other) and press .  
Your total bill appears, including tip.
4. If you want to split the bill, press  right and press  to select **Split**.
5. Press  to clear the default of 2 guests.
6. Enter the number of guests and press .  
The amount each guest pays is calculated.

## Calculator




Use the calculator for basic mathematical equations.

1. Select **Menu** → **Tools** → **Calculator**.
  2. Use the keypad to enter numbers.
  3. Press  to select mathematical operations.
- |   |        |   |          |   |               |
|---|--------|---|----------|---|---------------|
| = | equal  | + | add      | x | multiply      |
| ÷ | divide | - | subtract | - | decimal point |


- C** Clear all numbers entered and display a zero.
- MR** Display the value currently stored in memory.
- M+** Add the displayed digit to the value stored in memory.
- MC** Clear the value currently stored in memory.
- ±** Change the sign of the displayed number.
-  Clear one function or one digit from the screen. Hold down to clear all of the digits and operations and display a zero.
-  Exit the calculator and return to home screen.

## Timer


This timer counts down for a specified amount of time. It beeps when that amount of time has elapsed.

1. Select **Menu** → **Tools** → **Timer**.
2. Press  to **Set**.
3. Press  up or down to set the hours, minutes, and seconds. To move the cursor, press  left or right.
4. Select **Start** to begin the countdown.

Select **Stop** to pause the countdown.

5. When the alarm rings, press  to silence it.

## **Stopwatch**

1. Select **Menu** → **Tools** → **Stopwatch**.
2. Select **Start** to have the stopwatch begin counting.
3. Select **Stop** to stop counting.
4. Select **Reset** to set the counter back to zero and begin counting again.  
Press  when finished.

# INDEX

---

## Numerics

- 1-Touch dialing, 14
- 911 calls, 12

## A

- airplane mode, 12
- Alarm Clock, 7, 53
- alerts
  - for headsets, 46
  - for messages, 46
  - for missed calls, 13
- Auto-Erase setting, 24
- auto-hyphenation, 44
- AutoText, 21, 25

## B

- backlighting, 43
- balance, 3
- banner, 42
- battery, 1
  - drain, 2
  - removing, 2
  - safety guidelines, 2

- Brick Attack, 30
- button, 16

## C

- Calculator, 54
- calling emergency numbers, 12
- calls
  - making and answering, 3
  - missed, 13
- color themes, 44
- contacts
  - business, 35
  - calling, 38
  - classifying, 35, 36
  - editing, 36
  - editing phone number, 36
  - erasing, 36
  - finding, 37
  - personal, 35
- Contacts directory, 34
- Countdown Timer, 54

## D

- digital mode, 7
- display contrast, 44
- Doodler, 31

## E

- emergency
  - 911 calls, 12
  - making calls after dialing 911, 12
  - position location, 7, 46
- emoticons, 21
- erasing
  - all contacts, 46
  - text messages, 24

## F

- Fast Find, 38
- finding a saved phone number, 37
- frequent contacts, 37

## G

- games
  - Brick Attack, 30
  - Doodler, 31
  - MTV, 33
  - Race 21, 30
  - Tetris, 29
- group lists
  - creating, 25
  - using, 20

## H

- hands-free car kit
  - answering using voice, 50
- hands-free headset
  - and phone ringer, 46
  - purchasing, v
- hard pause, 35

## I

- icons, 7
- InBox, 23
- Internet browser, 27

## L

- lights
  - backlighting, 43
  - power backlighting, 43
- limiting calls out, 45
- lock code, 44
- locking
  - phone, 45

## M

- memory
  - saving, 24
- menu view, 42
- messages
  - erasing, 24
  - reading, 23
  - retrieving, 23
  - sending, 21

- signature, 22
- viewing, 22
- missed calls, 13
- \*MTV, 28
- \*MTV Games, 33

## N

- normal text mode, 17
- number mode, 17
- number type, 34

## O

- open to answer, 12
- OutBox, 22

## P

- pauses in phone numbers, 35
- Phone Account
  - bonus, 9
  - check balance, 9
  - top-up, 9
- phone book
  - see Contacts directory
- phone numbers
  - editing, 36
  - finding quickly, 38
  - types of, 34
  - verifying your own, 3
- phone, unlocking, 45
- position location
  - for finding phone, 46

- indicators, 7
- settings, 46

- power backlighting, 43
- prepend, 14, 37

## R

- Race 21, 30
- redialing a number, 10
- resetting the phone, v
- ringers
  - silencing, 3
  - volume, 41
- ringtones
  - choosing, 40
- Ringtones
  - for different callers, 41

## S

- saved phone numbers
  - editing, 36
  - finding quickly, 38
  - searching for, 38
- Scheduler, 53
- screen icons, 7
- screen savers, 42
- searching for saved phone numbers, 38
- secret contacts, 14, 35
- security, 44
- setting, 40
- shortcuts

- accessing, 42
- signal strength, 7
- silencing all sounds, 40
- silent mode, 40
- speakerphone, 16
- speed dialing, 14
- Stopwatch, 55
- symbol mode, 18

**T**

- Tetris, 29
- text entry
  - changing text modes, 18
  - eZiText mode, 17
  - normal text mode, 17
  - number mode, 17
  - symbol mode, 17
- text messages
  - emoticons, 21
  - erasing, 24
  - pre-written (AutoText), 21, 25
  - retrieving, 23
  - to multiple recipients, 25
  - viewing the outbox, 22
- time pause, 35
- time/date format, 42
- Tip Calculator, 54
- Top-Up, 9

**U**

- unlocking the phone, 45

**V**

- vibrate
  - setting phone to, 40
  - silence all, 40
- VirginXtras, 27
- voice dial
  - digit dialing, 49
  - expert mode, 49
- voice memo
  - erasing, 52
  - naming, 52
  - playing, 52
- Voice Recognition
  - digit dialing, 49
  - expert mode, 49
  - voice dialing, 48
    - add to new contact, 34
  - voice training, 51
  - voice wake-up, 50
- voicemail
  - accessing, 15
  - setting up, 3, 15
- volume
  - earpiece, 41
  - key beep, 41
  - ringer, 41

**W**

- wallpaper, 44

**X**

- Xtras, 27

